

Loading the TeleFlight Stair Inventory Cart



Step 1 Disassemble TeleFlight Stair as per manual, place handrails to the side until step 3, Remove the top 16 balusters (G) (bumps) per manual and place in the compartment at the front of the cart.

****Note: The balusters must be placed in alternating sequence with chains on top.**

The remaining 20 balusters (A) (no bumps) are stored in the back compartment of the cart chains on top



Step 2 The first 9 Tread Assemblies are to be placed upside down starting at the back of the cart, slide on to the middle bar and firmly push to the back of the cart.

****Note: Tread assemblies must be tightly positioned together****



Step 3 Handrails are to be placed on both sides of cart resting in the channel of the bottom row of treads , place the handrail toward the back of the cart into the angled side plate then maneuver the handrail till it fits behind the notch in the front of the cart.



Step 4 Place the remaining 9 Tread assemblies upside down starting at the back of the cart tightly.



Step 5 Stringers will be placed on either side of the cart, feet end in first to the front of the cart behind the tab, dropping into the tread channel, slide stringer to back of cart behind the tab until it stops



Step 6 Place the Top Mount Barricade over the baluster compartment on the front of the cart, then Place Safety T-Bar at the end of the stringers over the barricade in front of the cart.



Step 7 Place Top and Bottom Mounting plates together and drop upside down over the Safety T-Bar until they drop into place.



Step 8 Place Instructions and loose parts in the Parts Box and place in the compartment at the front of the cart.



- 1 Top Mounting Plate
- 2 Telescoping Stringer Assemblies
- 1 Bottom Mounting Plate
- 18 Tread Assemblies
- 20 Baluster (A)
- 16 Baluster (B)
- 2 Telescoping Handrail Assemblies
- 1 Top Mount Barricade
- 1 Safety T-Bar